



## DIN RAIL SMART METER FOR SINGLE AND THREE PHASE ELECTRICAL SYSTEMS

User Manual V1.6

### Warnings

Important Safety Information is contained in the Maintenance section. Familiarize yourself with this information before attempting installation or other procedures. Symbols used in this document:

**!** Risk of Danger: These instructions contain important safety information. Read them before starting installation or servicing of the equipment.

**!** Caution: Risk of Electric Shock

## 1. Introduction

This document provides operating, maintenance and installation instructions. These units measure and display the characteristics of single phase two wire (1p2w), three phase three wire (3p3w) and three phase four wire (3p4w) networks. The measuring parameters include voltage (V), frequency (Hz), current (A), power (kW/kVA/kVAr), import, export and total Energy (kWh/kVAh). The units can also measure maximum demand current and power, this is measured over preset periods of up to 60 minutes.

These units are Max. 100A direct connected and do not need to connect with external current transformers (CT). Built-in pulse, RS485/Mbus outputs. Configuration is password protected.

### 1.1 Unit Characteristics

The SDM630 100A V2 series meters have 7 models: SDM630-Pulse V2, SDM630-MT V2, SDM630-Mbus V2, SDM630-Mbus V2, SDM630-Standard V2, SDM630-2T V2, SDM630-Mbus-2T.

Model	Measurement	Communication	Tariff
SDM630-Pulse V2	kWh/kVAh, kW/kVA, kVA, P, F, PF, dmd, V, A, THD, etc.	NO	NO
SDM630-Standard V2	kWh/kVAh	RS485 Modbus	NO
SDM630-Mbus V2	kWh/kVAh, kW/kVA, kVA, P, F, PF, dmd, V, A, THD, etc.	RS485 Modbus	NO
SDM630-Mbus-2T	kWh/kVAh, kW/kVA, kVA, P, F, PF, dmd, V, A, THD, etc.	Mbus EN13757-3	NO
SDM630-4T V2	kWh/kVAh, kW/kVA, kVA, P, F, PF, dmd, V, A, THD, etc.	RS485 Modbus	4 Tariffs (RTU)
SDM630-2T V2	kWh/kVAh, kW/kVA, kVA, P, F, PF, dmd, V, A, THD, etc.	RS485 Modbus	2 Tariffs (dual source)
SDM630-Mbus-2T	kWh/kVAh, kW/kVA, kVA, P, F, PF, dmd, V, A, THD, etc.	Mbus EN13757-3	2 Tariffs (dual source)

### 1.2 RS485 Serial-Modbus RTU

\*Not for SDM630-Pulse V2, SDM630Mbus V2

and SDM630Mbus-2T

RS485 serial port with Modbus RTU protocol to provide a means of remotely monitoring and controlling the unit. Set-up screens are provided for setting up the RS485 port. Refers to section 4.2

### 1.3 Mbus

\*For SDM630-Mbus V2 and SDM630Mbus-2T only

This uses a MBus port with EN13757-3 protocol to provide a means of remotely monitoring and controlling the unit.

Set-up screens are provided for setting up the MBus port.

Refers to section 4.2

\*If the Modbus / Mbus protocol document is required, please contact us for it.


### 1.4 Pulse Output

Two pulse outputs that pulse measured active and reactive energy. The constant of pulse output 2 for active energy is 400imp/kWh (non-unconfigurable), its width is fixed at 100ms.

The default constant of pulse output 1 is 400imp/kWh, default pulse width is 100ms. Both pulse constant and pulse width are configurable through set-up menu or communication.

Refers to section 4.3

## 2. Start Up Screens



The first screen lights up all display segments and can be used as a display check.

Software version information (This information is for reference only, in kind prevail.)

The interface performs a self-test and indicates the result if the test passes.

\*After a short delay, the screen will display active energy interface as follows:



## 3. Measurements

The buttons operate as follows:

<b>U/I</b>	Selects the Voltage and Current display screens. In Set-up Mode, this is the "Left" or "Back" button.
<b>M</b>	Select the Frequency and Power factor display screens. In Set-up Mode, this is the "Up" button.
<b>P</b>	Select the Power display screens. In Set-up Mode, this is the "Down" button.
<b>E</b>	Select the Energy display screens. In Set-up mode, this is the "Enter" or "Right" button.

### 3.1 Voltage and Current

\*Not for SDM630-Standard V2.

Each successive press of the **U/I** button selects a new parameter:

L <sup>1</sup>	0.000 V	Phase to neutral voltages.
L <sup>2</sup>	0.000	
L <sup>3</sup>	0.000	
L <sup>1</sup>	0.000 A	Current on each phase.
L <sup>2</sup>	0.000	
L <sup>3</sup>	0.000	
L <sup>1</sup>	0.000 V %THD	Phase to neutral voltage THD%
L <sup>2</sup>	0.000	
L <sup>3</sup>	0.000	
L <sup>1</sup>	0.000 I%THD	Current THD% for each phase
L <sup>2</sup>	0.000	
L <sup>3</sup>	0.000	

### 3.2 Frequency and Power Factor and Demand

\*Not for SDM630-Standard V2

Each successive press of the **M** button selects a new range:

<b>Σ</b> 0.000 Hz	Frequency and Power Factor (total).	
0.999	PF	
L <sup>1</sup>	0.999	
L <sup>2</sup>	0.999	
L <sup>3</sup>	0.999 PF	
L <sup>1</sup>	0.000 A	Maximum Current Demand.
L <sup>2</sup>	0.000	
L <sup>3</sup>	0.000	
MD	0.000 kW	Maximum Power Demand.
Σ	0.000	

### 3.3 Power

\*Not for SDM630-Standard V2

Each successive press of the **P** button select a new range:

L <sup>1</sup>	0.000 kW	Instantaneous Active Power in kW.
L <sup>2</sup>	0.000	
L <sup>3</sup>	0.000	
L <sup>1</sup>	0.000 kVA	Instantaneous Reactive Power in kVA.
L <sup>2</sup>	0.000	
L <sup>3</sup>	0.000	
L <sup>1</sup>	0.000 kVA	Instantaneous Volt-Amps in kVA.
L <sup>2</sup>	0.000	
L <sup>3</sup>	0.000	
Σ	0.000 kW	Total kW, kVA, kVA.
Σ	0.000 kVA	
Σ	0.000 kVA	

### 3.4 Energy Measurements

Each successive press of the **E** button selects a new range:

0.000 kWh	Total active energy in kWh.
Σ 03.14	

## 3. Measurements

The buttons operate as follows:



Export active energy in kWh.



Tariff 1~4 active energy

\*For SDM630-MT V2 only



Total reactive energy



Import reactive energy



Export reactive energy



Tariff 1~4 reactive energy

\*For SDM630-MT V2 only



Date

Year/month/day.

1st,Jan,2000 (default)

\*For SDM630-MT V2 only



Time

Hour/minute/second

Example:00:02:16

\*For SDM630-MT V2 only

\*The parameters of date and time can only be set via RS485 communication.

## 4. Set Up

To enter set-up mode, press the **E** button for 3 seconds until the password screen appears.

<b>PASS</b>	Setting up is password-protected. The user must enter the correct password (default '1000') before processing.
<b>Err</b>	If an incorrect password is entered, the display will show:  PASS Err

To exit setting-up mode, press **U/I** repeatedly until the measurement screen is restored.

### 4.1 Set-up Entry Methods


Some menu items, such as password, require a four-digits number entry while others, such as supply system, require selection from a number of menu options.

#### 4.1.1 Menu Option Selection

1. Use the **M** and **P** buttons to scroll through the different options of the set up menu.
2. Press **E** to confirm your selection
3. If an item flashes, then it can be adjusted by the **M** and **P** buttons.
4. Having selected an option from the current layer, press **E** to confirm your selection.
5. Having completed a parameter setting, press **U/I** to return to a higher menu level, and you will be able to use the **M** and **P** buttons for further menu selection.
6. On completion of all setting-up, press **U/I** repeatedly until the measurement screen is restored.

#### 4.1.2 Number Entry Procedure

When setting up the unit, some screens require the entering of a number. In particular, on entry to the setting up section, a password must be entered. Digits are set individually, from left to right. The procedure is as follows:



Press **E** to confirm the setting and press **W1** to return to the main set up menu.


#### 4.3.1 Pulse Rate

Use this to set the energy represented by each pulse.

Rate can be set to 1 pulse per

dF0/0.1/1/10/100kWh/kVAh.

(It shows 1 pulse = 10kWh/kVAh)




Use **M** and **P** buttons to choose pulse rate, then press **E** to confirm the setting and press **W1** to return to the main set up menu.

#### 4.3.2 Pulse Duration

The pulse width can be selected as 200, 100 (default) or 60ms.

(It shows pulse width of 100ms)




Use **M** and **P** buttons to choose pulse rate, then press **E** to confirm the setting and press **W1** to return to the main set up menu.

#### 4.4 DIT Demand Integration Time

\*Not for SDM630-Standard V2


This sets the period in minutes over which the current and power readings are integrated for maximum demand measurement. The options are: 0, 5, 8, 10, 15, 20, 30, 60 minutes.



Press **W1** to exit the DIT selection routine and return to the menu.

#### 4.5 Backlit Set-up

Backlit lasting time is settable, default lasting time is 60minutes



Press **M** and **P** to select the time interval. Then press **E** to confirm the set-up.

#### 4.6 Supply System

The unit has a default setting of 3 phase 4 wire (3P4W). Use this section to set the type of electrical system.

Press **E** to enter the selection routine. The unit symbol will flash.

Use **M** and **P** buttons to choose the selection

From the set-up menu, use **M** and **P** buttons to select the system option. The screen will show the currently selected system type.

Press **E** to enter the selection routine. The current selection will flash.

From the set-up menu, use **M** and **P** buttons to select the required system option: 1P2 (W), 3P3 (W), 3P4 (W). Press **E** to confirm the selection.

Use **M** and **P** buttons to select the required system option: 1P2 (W), 3P3 (W), 3P4 (W). Press **E** to confirm the selection.

Press **W1** to exit the system selection routine and return to the menu.

#### 4.7 CLR

\*Not for SDM630-Standard V2

The meter provides a function to reset the maximum demand value of current and power.

From the set-up menu, use **M** and **P** buttons to select the reset option.

Press **E** to enter the selection routine. The MD will flash.

#### 4.8 Change Password

Use the **M** and **P** to choose the change password option.

Press the **E** to enter the change password routine. The new password screen will appear with the first digit flashing.

Use **M** and **P** to set the first digit and press **E** to confirm your selection. The next digit will flash.

Repeat the procedure for the remaining three digits. After setting the last digit, Press **E** to confirm the selection.

Press **W1** to exit the number setting routine and return to the Set-up menu.

### 5. Specifications

#### 5.1 Measured Parameters

The unit can monitor and display the following parameters of a single phase two wire (1p2w), three phase three wire (3p3w) or three phase four wire (3p4w) system.

#### 5.1.1 Voltage and Current

\*Not for SDM630-Standard V2

- Phase to neutral voltages 176 to 276V a.c. (not for 3p3w supplies).
- Voltages between phases 304 to 480V a.c. (3p supplies only).
- Percentage total voltage harmonic distortion (THD%) for each phase to N (not for 3p3w supplies).
- Percentage voltage THD% between phases (three phase supplies only).
- Current THD% for each phase

#### 5.1.2 Power factor and Frequency and Max. Demand

\*Not for SDM630-Standard V2

- Frequency in Hz
- Power factor
- Instantaneous power:
- Power 0 to 99999 W
- Reactive power 0 to 99999 VAr
- Volt-amps 0 to 99999 VA
- Maximum demanded power since last Demand reset
- Maximum neutral demand current, since the last Demand reset (for three phase supplies only)

#### 5.1.3 Energy Measurements

- Import active energy 0 to 999999.99 kWh
- Export reactive energy 0 to 999999.99 kVAh
- Import active energy 0 to 999999.99 kWh
- Export reactive energy 0 to 999999.99 kVAh
- Total active energy 0 to 999999.99 kWh
- Total reactive energy 0 to 999999.99 kVAh

#### 5.2 Measured Inputs

Voltage inputs through 4-way fixed connector with 25mm<sup>2</sup> stranded wire capacity. single phase two wire (1p2w), three phase three wire (3p3w) or three phase four wire (3p4w) unbalanced. Line frequency measured from L1 voltage or L3 voltage.

#### 5.3 Interfaces for External Monitoring

Three interfaces are provided:


- RS485/Mbus communication channel that via protocol remotely. (not for SDM630-Pulse V2)
- Pulse output (pulse1) indicating real-time measured energy. (configurable)
- Pulse output (pulse2) 400imp/kWh (non-configurable)

The Modbus/Mbus configuration (baud rate etc) and the pulse output assignments (kW/kVAh, import/export etc) are configured through the set-up screens


#### 5.4 Accuracy

• Voltage	0.5% of range maximum
• Current	0.5% of nominal
• Frequency	0.2% of mid-frequency
• Power factor	1% of unity (0.01)
• Active power (W)	±1% of range maximum
• Reactive power (VAr)	±1% of range maximum
• Apparent power (VA)	±1% of range maximum
• Active energy (Wh)	Class 1 IEC 62053-21
• Reactive energy (VArh)	Class 2 IEC 62053-23
• Response time to step input	1s, typical, to >99% of final reading, at 50 Hz.


#### 7.1 single phase two wire



#### 7.2 three phase three wire




#### 7.3 three phase four wire



#### 7.4 Terminals Capacity and Screw Torque

Terminals		
COMM/Pulse/2T	0.5~1.5mm <sup>2</sup>	0.4Nm
Load	4~25mm <sup>2</sup>	3Nm

### 6. Dimensions



### 7. Wiring diagram

